



JNIOR Series 4

A Network I/O Resource
Utilizing the JAVA™ Platform

LED Dimmer Module And the Analog Presets Program Manual Release 3.0

NOTE: This version only works with the JNIOR 410, 412, 414

INTEG Process Group, Inc.
2919 East Hardies Rd, First Floor
Gibsonia, PA 15044

PH (724) 933-9350
FAX (724) 443-3553

www.integpg.com

JNIORsales@integpg.com

© 2015 INTEG Process Group, Inc.
All Rights Reserved

Last updated on: September 4, 2015

TABLE OF CONTENTS

1	Wiring the LED Dimmer Module.....	3
2	Using the JNIOR Web Page to Control the LED Dimmer Module.....	4
3	What is the Analog Presets Program?.....	5
4	The Purpose of the Analog Presets Program	5
5	Installing the Analog Presets Program.....	5
6	Configuring the Analog Presets Program	6
6.1	Levels	8
6.2	General Settings	10
6.2.1	Global Transition Time.....	10
6.2.2	Remote Control Server	11
6.2.3	Remote Control via the INTEG Cinema Program.....	12
6.3	View Application Log.....	13
7	Utilizing Your New Settings.....	13
8	Using the JR Color Wheel Application	14
APPENDIX – Relay Output Control Commands.....		16

1 Wiring the LED Dimmer Module

The LED Dimmer module has 3 Channels of control. You can control up to 3 different white LED strip lights or 1 set of color (RGB) LED strip lights per LED Dimmer module.

Each channel can handle up to 10 amps. The expansion module can handle up to 30 amps total.

Each channel uses Pulse Width Modulated (PWM) control to vary the LED strip lighting intensity between 0 and 100%. The voltage is controlled on the **negative side** to conform with most standard LED strip lights.

NOTE: For white LED strips, connect the + and – wires to the + and – OUTPUT terminals for one of the LED Dimmer channels. For colored LED strips, connect the Red, Green and Blue wires to the – OUTPUT terminals for each of the three LED Dimmer channels. The common wire (fourth wire) coming from the colored LED strip is connected to the + OUTPUT on only one of the LED Dimmer Channels. You do not need to jumper all three of the + OUTPUT connections on the LED Dimmer channels.

A 5 – 24 VDC power supply must be connected to the dimmer module on the + - INPUT terminals to power the LED strip lights. The voltage should match the voltage required by your LED strip lights.

The LED Dimmer expansion module connects to the Sensor port on the JNIOR Series 4 and can be up to 50 feet away from the JNIOR.

You can use up to **four (4) LED Dimmer modules per JNIOR.**

NOTE: The LED Dimmer module ONLY works with the JNIOR – the Series 4 consisting of the models 410, 412 and 414.



2 Using the JNIOR Web Page to Control the LED Dimmer Module

You can manually set the desired output for each channel of the LED Dimmer module using the JNIOR Configuration web page. This web page is launched from the JNIOR Support Tool – Beacon tab or by typing the JNIOR IP address and then /configure For example: <http://10.0.0.201/configure>

After the web page is loaded, go to the I/O Control and then External tab. One to four LED modules will be displayed as shown below. The LED Channels will be numbered 1-3 on the first module and then 4-6, 7-9 and 10-12 on the subsequent modules. The modules are numbered according to how they are discovered on initial boot.

You can control an individual output setting by clicking on the Set button for the appropriate channel. You can control all 3 channels for 1 module by clicking on the button for the Set Block command as shown below.

New Value

Enter either a #hexcolor or comma separated list of values (0 - 100) %

40,50,60

OK Cancel

Set Block Pop-Up

LED_Controller

I/O Control Configuration Registry Editor Command Line Applications About

Internal External

3 Channel Dimmer Module 9C110001678C95F9		
OUTPUTS		
1 - Channel 1	0.00 %	Set
2 - Channel 2	0.00 %	Set
3 - Channel 3	0.00 %	Set
Set Block		Set

3 Channel Dimmer Module 60111150213098F9		
OUTPUTS		
4 - Channel 1	0.00 %	Set
5 - Channel 2	0.00 %	Set
6 - Channel 3	0.00 %	Set
Set Block		Set

3 Channel Dimmer Module 7B1100016771C8F9		
OUTPUTS		
7 - Channel 1	0.00 %	Set
8 - Channel 2	0.00 %	Set
9 - Channel 3	0.00 %	Set
Set Block		Set

3 Channel Dimmer Module E5111150213091F9		
OUTPUTS		
10 - Channel 1	0.00 %	Set
11 - Channel 2	0.00 %	Set
12 - Channel 3	0.00 %	Set
Set Block		Set

[Search Again](#)

3 What is the Analog Presets Program?

The Analog Presets program is a program that runs on the JNIOR that allows the user to implement multiple levels of analog control that can be sent to the analog output on the JNIOR analog expansion modules. The program works with the **LED Dimmer module**, the 0 – 10 VDC analog expansion module, and the 4 – 20 mA analog expansion module. It will work with up to four of the LED Dimmer modules and one or two of the other analog expansion modules per JNIOR. They can be the same type of module or different types.

4 The Purpose of the Analog Presets Program





The Analog Presets Program is meant to be a stepped analog control solution with optional relay output control. It is a way to allow the user to define specific analog values to be sent to the JNIOR analog outputs whenever a ‘trigger’ occurs. The trigger can be a change in state of a digital input or relay output, or a ‘message’ can be sent from another device or the INTEG Cinema program to the Analog Presets program. The amount of time it takes to transition from the current analog level to the new analog level can be adjusted.

5 Installing the Analog Presets Program

The Analog Presets Program is an add-on program. INTEG distributes the program via an Update Project that is used with the JNIOR Support Tool. The JNIOR Support Tool and Analog Presets Program Update Zip can both be downloaded from the INTEG website at the following:

<http://www.integpg.com/support/jnior/>

NOTE: Please make sure you install the version for the Series 4 JNIOR.

ANALOG PRESETS CONTROL				
Analog Presets for 310, 312, 314	March 15, 2011	1.2.315.1253	 Download	 Release Notes
Analog Presets for 410, 412, 414	February 26, 2015	1.0.1.23	 Download	 Release Notes


Series 4

NOTE: The current version on the website may differ from what is shown here.

Manual

Please click on the Download and save the zip file. Do NOT unzip it. The JNIOR Support Tool will unzip it. Go to the Update Tab in the JNIOR Support Tool and select Open Project and then navigate to where you saved the zip file. The JNIOR Support Tool will unzip the update project and show you all the steps.

When you run the Update Project, the project will load the software, set the program to run on boot and cause the JNIOR to reboot so the program is started.



6 Configuring the Analog Presets Program


After the Analog Presets Program has been loaded on to the JNIOR and rebooted, the Analog Presets Program can be configured via the Analog Presets web page.

NOTE: You must use a 'modern browser' which is defined as Internet Explorer 10 or greater, Google Chrome or Firefox for the Analog Presets web page.


To launch the Analog Presets web page, type the IP address of your JNIOR in your Web browser address line followed by /analogpresets

An example is as follows: <http://192.168.1.210/analogpresets>

When you launch the Analog Presets web page, you will be asked to log in. Please use the default JNIOR username (jnior) and password (jnior).



The web page on the Levels tab looks as follows:




6.1 Levels

The Analog Presets Program can have many different ‘Levels’. Each level can contain multiple analog outputs to be controlled. Each Level contains unique settings for that Level.

Each Level is given a unique name and this is the name that can be sent from another program or device to ‘trigger’ the Level.

From the Analog Presets web page, click on the ADD LEVEL button at the bottom of the web page to add a level. **The Level name cannot contain any spaces.** Please use an underscore to separate words.

As you mouse over each area to be configured, a help window will be displayed providing you with details on the information to be entered. An example is shown below for the Setting Level box.



The screenshot shows a web form with two input fields. The top field is labeled 'Setting Level' and the bottom field is labeled 'Trigger'. A black tooltip box with white text is positioned over the 'Setting Level' field, containing the instruction: 'Enter the Channel Level as 0 – 100%. Different values for each channel being controlled with this Level are separated by commas.'

Data to be entered is as follows. Fields not being used can be left blank.

Name – enter the name for the Level, but you can change it anytime

Setting Level – enter the value to be set for the channel. The number ranges from 0 – 100% and can be for one channel or multiple channels where each value is separated by commas. For example, 20,0,50,10,30,40 would be the value for 6 channels.

Trigger – the level can be triggered by a JNIO digital input or relay output going from ‘off’ to ‘on’. The format, for example, is DIN1 or ROUT1 (where 1 = 1 through 8)

Transition Time – this is the amount of time in milliseconds that the JNIO will take to transition the channel settings from the current value to the new value in equal increments **for THIS LEVEL ONLY**. A zero (0) indicates an immediate transition to the new value. If the value is blank, then the Global Transition time under the General Settings is used.

4-20ma Output Channels – If a 4-20ma analog expansion module is not connected to the JNIO, this box will be greyed out.

Enter the channel(s) to be controlled separated by a comma
 Acceptable values: 1, 2, 3, 4 (if NOT USED leave blank or -1)
 1 and 2 are the outputs on the first 4-20 expansion module
 3 and 4 are the outputs on the second 4-20 expansion module

10v Output Channels – If a 10 v analog expansion module is not connected to the JNIOR, this box will be greyed out.

Enter the channel(s) to be controlled separated by a comma
 Acceptable values: 1, 2, 3, 4 (if NOT USED leave blank or -1)
 1 and 2 are the outputs on the first 10 v expansion module
 3 and 4 are the outputs on the second 10 v expansion module

3 Channel LED Output Channels – If a 3 Channel LED expansion module is not connected to the JNIOR, this box will be greyed out.

Enter the channel(s) to be controlled separated by a comma
 Acceptable values: 1 to 12 (if NOT USED leave blank or -1)
 1, 2 and 3 are the outputs on the 1st LED Dimmer module
 4, 5 and 6 are the outputs on the 2nd LED Dimmer module
 7, 8 and 9 are the outputs on the 3rd LED Dimmer module
 10, 11 and 12 are the outputs on the 4th LED Dimmer module


Start Relay Output Action – a relay output (or multiple relay outputs) to be controlled when the level transition **STARTs**.

End Relay Output Action – a relay output (or multiple relay outputs) to be controlled when the level transition **ENDs**.

Example Relay Output Actions

Action(s) can be entered for one or more relay outputs
 Acceptable values: **See Appendix A**
 For example, a value of `c1` would close output 1
 A value of `o1` would open output 1
 A value of `c1p=1000` would pulse closed output 1 for 1 second

The buttons at the bottom of the web page are used to Save your changes, Cancel your changes, Add a Level, Remove a Level or Test the level (after you have saved your changes).



Please note that your changes take effect immediately after you save them. You do NOT have to reboot the JNIOR for the changes to take effect.

6.2 General Settings

By clicking on the General tab at the Analog Presets web page, the following web page is displayed.

The screenshot shows the 'General' settings page for Analog Presets. The page has a dark header with the following elements: 'Analog Presets' (selected), 'Levels', 'General', 'View Application Log', and 'v 1.2.0.248'. The main content area is titled 'General' and contains the following settings:

- Global Transition Time:** 5000
- Remote Control Server:**
 - TCP Port:** 9700
 - Termination String:** \r\n

Below the settings is a note: "You can send messages to the server by connecting to the IP Address of the unit and the defined TCP port and sending trigger <level name> followed by the defined termination string." At the bottom of the form are two buttons: 'Save' (blue) and 'Cancel' (orange).

6.2.1 Global Transition Time

The Global Transition Time is the amount of time, in milliseconds, that the JNIOR will take to make the transition from the current 'analog output' value being used by the expansion module to the new value defined in the Level that was triggered. The JNIOR will make this transition in steps of approximately equal amounts until the new value is reached. **The Global Transition Time applies to all 'levels' unless a specific Level has a transition time defined that will override the global transition time for that Level.**

The default value is 5000 milliseconds (5 seconds) and a 0 indicates an immediate sending of the new value

6.2.2 Remote Control Server

The Analog Presets Program can receive the command ‘trigger level_name’ from one or more clients and the Analog Presets Program will immediately execute that Level.

On the General Settings tab, as shown above, the user can configure the port that is ‘listening’ on the JNIOR to receive commands. The default port is 9700, but it can be changed to any valid port. Multiple connections can be made to this port.

A termination string must be sent by the sending device at the end of the command. The default is `\r\n`. The valid choices are:

- `\r\n` - which is a carriage return (0D), line feed (0A)
- `\r` - which is just a carriage return
- `\n` - which is just a line feed

NOTE: A reboot of the JNIOR is required to restart the Analog Presets program for these new settings to take effect.

Below is an example of a device sending a command to the Analog Presets program that makes the connection to port 9700 and maintains the connection. If the connection is maintained, the Analog Presets program will respond indicating that the trigger was executed successfully or not.

The screenshot shows a terminal window titled "JNIOR Command Line". The output is as follows:

```
Client Connected
trigger lights_high ← valid command sent
'lights_high' has been triggered ← JNIOR response
trigger lights_low ← invalid command sent
'lights_low' does not exist ← JNIOR response
trigger lights_off
'lights_off' has been triggered
```


At the bottom of the window, there is a control bar with a "Disconnect" button, a "TCP / IP" dropdown menu, IP address fields (10.0.0.252), a port field (9700) which is circled in red, a "Clear" button, and an "Options" dropdown menu.

6.2.3 Remote Control via the INTEG Cinema Program


The Analog Presets Program can also be controlled from macros utilized by the INTEG Cinema program. The Cinema program can be loaded on the same JNIOR running Analog Presets or a different JNIOR or multiple JNIOs because multiple connections can be made to the Analog Presets program.

Please see the INTEG website Support section for additional details on loading and configuring the Cinema program. Below is a summary of how to connect to the Analog Presets program and send the trigger commands.

In order to trigger Levels used by the Analog Presets program, the JNIOR running the Analog Presets program must be configured as a Raw Ethernet device as part of the Devices file for the JNIOR running the Cinema program (the same or different JNIOR) as shown below.




Macros are then created that will send the ‘Trigger’ command to the Analog Presets program as shown below.



6.3 View Application Log

By clicking on the View Application tab on the Analog Presets web page, the following web page is displayed showing the information stored in the analogpresets.log file.



```

Analog Presets  Levels  General  View Application Log  v 1.2.0.248

Application Log

09/01/15 14:32:39 UTC, -- -----
09/01/15 14:32:42 UTC, -- AnalogPresets v1.2.0.248
09/01/15 14:32:42 UTC, -- built at 9/1/2015 9:38:26 AM
09/01/15 14:32:42 UTC, -- using Janos Lib v1.0.5
09/01/15 14:32:42 UTC, -- Application UUID: G8E497H
09/01/15 14:32:42 UTC, -- JANOS v1.3
09/01/15 14:32:42 UTC, -- Process ID: 3
09/01/15 14:32:43 UTC, -- Listening for clients on port 9700.
09/01/15 14:32:47 UTC, WebSocket client connected: 10.0.0.27:62960
09/01/15 14:39:34 UTC, WebSocket client disconnected: 10.0.0.27:62960
09/01/15 15:49:48 UTC, WebSocket client connected: 10.0.0.114:55385
09/01/15 15:49:52 UTC, 10.0.0.114:55385 logging in
09/01/15 15:50:00 UTC, WebSocket client disconnected: 10.0.0.114:55385

```


7 Utilizing Your New Settings

After you have changed any of your settings and clicked on the SAVE button, the changes will take effect immediately except for the Remote Control Server configuration. Changes to the Remote Control Server configuration require a reboot.

8 Using the JR Color Wheel Application

In order to control the LED Dimmer module with colored LED strip lights (RGB), you will need to set each of the 3 channels to a certain percentage to get that color. INTEG currently has a BETA version of a software program that can be loaded on the JNIOR Series 4 that provides a ‘color wheel’ that will change the color and tell you the values you need for each channel.

The Update project to load the JR Color Wheel can be downloaded from the INTEG website and is shown below.



The JR Color Wheel application contains a web page that can be launched after you have loaded the program. Please type your JNIOR IP address then /jrcolor. An example is shown below.

<http://10.0.0.67/jrcolor>

To use the application, just ‘click’ on any location on the wheel. If you ‘drag’ the circle around the wheel, it may take a few seconds for the JNIOR to catch up to where you stop.

Dragging the smaller circle within the square will change the intensity of the LED.

The screen picture below shows the color wheel, slider bars to change the value output to each channel, the standard color value and the percentage output needed for each LED Dimmer channel to achieve the desired color.

Below the color is a box that allows you to enter the HEX value for a color and click on the Set Color button. You can also change the time it takes to transition from color to color as you select different color values on the wheel.

You can add a Level to the Analog Presets program that will send the three needed output values to achieve the desired color value.

jrColor

Channel 1 - Red
 R: 0 Percentage: 0

Channel 2 - Green
 G: 231 Percentage: 91

Channel 3 - Blue
 B: 0 Percentage: 0

Hex: #00e700 Set Color

Fade Time: 0 milliseconds

APPENDIX – Relay Output Control Commands

The following commands can be used for the RelayOutputAction value in each Level.

- cX** **Close the output** (relay is “on” closing the contact)
 where x = 1 through 8 for the internal relay outputs on the JNIOR 310
 and x = +1 through +8 for the external relay outputs on the 4 Relay Output
 Expansion Modules
- oX** **Open the output** (relay is “off” opening the contact)
 where x = 1 through 8 for the internal relay outputs on the JNIOR 310
 and x = +1 through +8 for the external relay outputs on the 4 Relay Output
 Expansion Modules
- p=yyy** **Pulse duration** (milliseconds) and is used in conjunction with the ‘close’
 or ‘open’ command

Examples:

c2p=1000	close output 2 for 1 second and then open again
c+2p=1000	close output 10 for 1 second and then open again
o3p=10000	open output 3 for 10 seconds and then close again

- c*** Close all outputs at the same time (includes internal and external)
- o*** Open all outputs at the same time (includes internal and external)

These commands can be abbreviated and used in combination, such as:

- c1 close relay output 1
- c+1 close relay output 9 (first output on first expansion module)
- c+5 close relay output 13 (first output on second expansion module)
- c1+1+5 combination of the above all in one command
- c1234 close relay outputs 1 through 4
- c1368 close relay outputs 1, 3, 6, 8
- o125 open relay outputs 1, 2, 5
- c1+1p=1000 close relay outputs 1, 9 and pulse each for 1 second simultaneously

Summary

Thank you for purchasing the **JNIOR**. Hopefully this manual made the getting-to-know process of your new **JNIOR** very quick and easy. The **JNIOR** has many more wonderful tools and features available, and are explained in detail in the supplied documents.

Copyright	Copyright © 2015 INTEG Process Group, Inc. All rights reserved.
Notice	Every effort was made to make this manual as accurate and useful as practical at the time of the writing of this manual. However, all information is subject to change.
Trademarks	Trademarks are the property of their respective holders. Java is a trademark or registered trademark of Oracle (Sun Microsystems, Inc.) in the United States and other countries. Microsoft, Windows, MS-DOS and Internet Explorer are registered trademarks of Microsoft Corporation.
Use Restrictions	This User's Manual and the software contained in the JNIOR are copyrighted by INTEG Process Group, Inc. and may not be copied or reproduced without prior consent from INTEG Process Group, Inc. INTEG Process Group, Inc. is not responsible for any errors or omissions that may be contained in this manual.

Please do not hesitate to contact our **JNIOR** team at **INTEG Process Group, Inc.** We can be reached via phone, fax or e-mail as follows:

INTEG Process Group, Inc.
2919 E. Hardies Road
1st Floor
Gibsonia, PA 15044

www.integpg.com

JNIORsales@integpg.com

PH (724) 933-9350 extension 20
FAX (724) 443-3553